



AUTHORIZED SERVICE CENTERS

MIDCONTINENT INSTRUMENTS AND AVIONICS ONTIC AUTHORIZED MRO CAPABILITIES LIST

To learn more about MidContinent Instruments and Avionics' Ontic Authorized MRO capabilities, get in touch with them on the details below.

E: bryanm@mcico.com

T: 800-345-7599



PART NUMBER	DESCRIPTION
037-05001-0000	KFS 594 DISPLAY
050-01343-0000	INSTALLATION KIT
050-01343-0003	INSTL. KIT CESSNA SPCL NO
050-01401-0000	INSTL KIT BLK PLT
050-01401-0001	INSTL KIT GRY PLT
050-01401-0002	INSTALLATION KIT
064-01015-0001	RCVR/EXCTR W/SEL
064-01015-0010	RX/EX W/SP PROC
064-01015-0011	RX/EX W/S P AND SCL
064-01015-0040	RX/EX MOD BW
064-01015-0041	RX/EX MOD BW SCL
064-01015-0051	RX/EX W/WBW DTANDSC
064-01015-0053	RX/EX W/SBW DTANDSC
064-01015-0061	FINAL ASSY
064-01016-0000	HF CONT 28V BLK
064-01016-0001	HF CONT 5V BLK
064-01016-0002	HF CONT 28V GRY
064-01016-0003	HF CONT 5V GRY
064-01016-0004	HF CONT 28V RB
064-01016-0005	HF CONT 115V NVG B
064-01016-0010	HF CTL 28V BK 23M
064-01016-0011	HF CTL 5V BK 23M
064-01016-0012	HF CTL 28V GY 23M
064-01016-0013	HF CTL 5V GY 23M
064-01016-0014	HF CTL 28V RB 23M
064-01017-0000	XCVR RMT AUTO CPLR
064-01017-0001	PWR AMP/ANT CPLR
064-01017-0002	XCVR RMI CPLR
064-01017-0011	FINAL ASSY
064-01017-0012	FINAL ASSY
064-01023-0000	FINAL ASSY 25K SEL
064-01023-0001	FINAL ASSY 50K SEL
064-01023-0002	FINAL ASSY 25K BB
064-01023-0003	FINAL ASSY 50K BB
064-01023-0004	25K SEL W/SELCAL
064-01023-0005	50K SEL W/SELCAL
064-01023-0006	25K BB W/SELCAL
064-01023-0007	50K BB W/SELCAL
064-01023-0008	FINAL ASSY 25K SEL
064-01023-0010	FINAL ASSY 25K JB
064-01065-0100	FINAL KTR909
064-01071-0101	KCU1051 FINAL ASSY
064-01071-0201	FINAL ASSEMBLY KCU1051
064-01071-0301	FINAL ASSEMBLY KCU 1051

PART NUMBER	DESCRIPTION
066-01044-0000	KMR675 MARKER BEACON RECEIVER
066-01044-0001	KMR675 BCN RCVR W/O TONE TEST
066-01066-0000	KDM0706A REMOTE DME -85DBM
066-01066-0001	KDM0706A REMOTE DME -90DBM
066-01066-0002	KDM0706A REMOTE DME -85DBM
066-01066-0011	KDM0706A REMOTE DME -90DBM
066-01066-0020	KDM0706A REM AGL DME-90DBM
066-01066-0022	KDM0706A REM DME 660 SYS
066-01066-0023	KDM0706A REM DME TRACK FLG
066-01066-0024	KDM0706A REM DME TRK FLG
066-01066-0025	KDM0706A DME W/AGL
066-01066-0031	KDM0706A REM DME AERMACCHI
066-01069-0002	KDI 573 SLV W/1H2
066-01069-0003	KDI 573 SLV W/O1H2
066-01069-0004	KDI 574 INDICATOR
066-01069-0005	KDI 574 W/O 1H2
066-01069-0014	KDI 574 GRY INDCTR
066-01078-0000	NAV RCVR GS MB RMI
066-01078-0001	NAV RCVR GS RMI
066-01078-0002	NAV RCVR MB RMI
066-01078-0003	NAV RCVR RMI
066-01078-0004	NAV RCVR GS MB
066-01078-0005	NAV RCVR GS
066-01078-0006	NAV RCVR MKR BCN
066-01078-0007	NAV RCVR CONV
066-01078-0008	NAV RECEIVER
066-01078-0010	NAV RCVR GS MB RMI
066-01078-0011	NAV RCVR GS RMI
066-01078-0012	NAV RCVR MB RMI
066-01078-0013	NAV RCVR RMI
066-01078-0014	NAV RCVR GS MB
066-01078-0015	NAV RCVR GS
066-01078-0016	NAV RCVR MKR BCN
066-01078-0017	NAV RCVR
066-01152-0101	KTA 810 FINAL ASSEMBLY
066-01175-0101	KMH 820 WO / GPS
066-01175-0102	KMH 820 W/O GPS
066-01175-2101	KMH 820 W/ GPS
066-01175-2102	KMH 820 W/ GPS
066-01175-2201	KMH 820 W/ GPS
066-01177-0101	KTA 910 FINAL ASSEMBLY
066-01178-0101	KMH 920 WO / GPS
066-01178-0102	KMH 920 W/O GPS
066-01178-2101	KMH 920 W / GPS

PART NUMBER	DESCRIPTION
066-01178-2102	KMH 920 W/ GPS
066-03060-0000	RADIO MAGNETIC IND
066-03060-0001	RADIO MAGNETIC IND
066-03060-0002	RADIO MAGNETIC IND
066-03060-0003	RADIO MAGNETIC IND
066-03060-0004	KNI 582 TACAN RMI
066-03060-0005	RADIO MAGNETIC IND
066-03060-0006	KNI582 28VB NVG
066-04034-0101	KLN900 GPS LNAV BK
066-04034-0102	KLN900 GPS LNAV BK
066-04034-0104	KLN 900 GPS PMO BK
066-04034-0201	KLN900 GPS LNAV GY
066-04034-0202	KLN900 GPS LNAV GY
066-04034-0204	KLN 900 GPS PMO GR
071-00019-0000	BRIDGING AMPLIFIER
071-01268-0001	HF BUS ADPTR EXLSB
071-01270-0000	DUAL EXT CAPACITOR
071-01270-0001	DUAL EXT CAPACITOR
071-01270-0002	DUAL EXT CAPACITOR
071-01274-0000	GC HF CONTROL HEAD
071-01274-0001	GC HF CONTROL HEAD
071-01274-0002	GC HF CONTROL HEAD
071-01274-0003	GC HF CONTROL HEAD
071-01274-0004	GC HF CONTROL HEAD
071-01438-0101	CP466A RDR BLK
071-01438-0102	CP466A RDR BLK
071-01438-0201	CP466A RDR GRAY
071-01438-0202	CP466A RDR GRAY
071-01438-0301	CP466A PROFILE BLK
071-01438-0302	CP466A VP BLK
071-01438-0401	CP466A PROFILE GRY
071-01438-0402	CP466A VP GRAY
071-01438-0502	CP466A LDET BLK
071-01438-0702	CP466A VP LDET BLK
071-01519-0101	FINAL ASSY ART2000
071-01546-0201	FINAL ASSY KFS599A
071-01546-0202	KFS 599A UHF CNTRL HEAD NO G/S
071-01546-0401	FINAL ASSY KFS599A
071-01546-1201	KFS599A FINAL ASY
071-01546-2201	FINAL ASSY KFS599A
071-01550-0101	FINAL ASSY ART2100
071-01550-0201	FINAL ASSY ART 2100
071-01576-1201	KFS599B FINAL ASSY
100-0120-03	Control Display Unit

PART NUMBER	DESCRIPTION
100-0120-07	Control Display Unit
100-0120-12	Control Display Unit
100-0127-01	Central Control Computer
100-0127-03	Central Control Computer
100-0649-01	Smoke Detector Unit
100-0649-02	Smoke Detector Unit
100-0649-04	Smoke Detector Unit
100-0649-05	Smoke Detector Unit
100-0649-06	Smoke Detector Unit
100-1019-01	Suppression Control Unit
100-1024-01	Configuration Module
100-1024-03	Configuration Module
100-1070-01	Central Control Computer
100-1070-02	Central Control Computer
100-1080-01	Central Control Computer
100-1080-02	Central Control Computer
100-1080-03	Central Control Computer
TE-1034-02	Halon Test Assy
213350	Box, Assy Control (Synchro)
213446	Box, Assy Control (Synchro)
213615	Box, Assy Control (Synchro)
213622	Box, Assy Control (Synchro)
213650	Box, Assy Control (Synchro)
213651	Box, Assy Control (Synchro)
213693	Box, Assy Control (Synchro)
213699	Box, Assy Control (Synchro)
213723	Box, Assy Control (Synchro)
213730	Box, Assy Control (Synchro)
213731	Box, Assy Control (Synchro)
213750	Box, Assy Control (Synchro)
213765	Box, Assy Control (Synchro)
213766	Box, Assy Control (Synchro)
213771	Box, Assy Control (Synchro)
213784	Box, Assy Control (Synchro)
213787	Box, Assy Control (Synchro)
213798	Box, Assy Control (Synchro)
213799	Box, Assy Control (Synchro)
5333-030	Rod End Assy, Speed Trimming
5430-952	Generator Assy, Speed Signal
5485-010	Actuator, Assy Synchronizer
5485-020	Actuator, Assy Synchronizer
5485-054	Actuator, Assy Synchronizer
5485-058	Actuator, Assy Synchronizer
5485-064	Actuator, Assy Synchronizer

PART NUMBER	DESCRIPTION
5485-066	Actuator, Assy Synchronizer
6852-910	Assy, Synchrophaser Control
6852-914	Assy, Synchrophaser Control
6852-920	Assy, Synchrophaser Control
A213796	Synchrophaser Control Box Assy
C213796	Synchrophaser Control Box Assy
F213796	Synchrophaser Control Box Assy
L213796	Synchrophaser Control Box Assy